

Manufacturer	Model	Description	Manufacturer Contact Details
<b>Box will stop working and viewers will need to replace equipment to continue receiving the Freeview service.</b>			
Daewoo	DS608P	Set-top box	Daewoo 0870 100 2525
Labgear	DTT100	Set-top box	No longer trading
Triax	DVB 2000T	Set-top box	No longer trading
Portland	DP100	Set-top box	Portland 0870 100 2525
Daewoo	SV900	Combined set-top box and VCR	Daewoo 0870 100 2525
Bush	IDVCR01	Combined set-top box and VCR	Bush 0871 230 1777
<b>BBC and ITV channels move into the 800's.</b>			
Daewoo	DS700	Set-top box	Step- 01 contact@step01.co.uk
Bush	DFTA3	Set-top box	Step- 01 contact@step01.co.uk
Ferguson	FDT500	Set-top box	Thomson 01788 541970
Ferguson	FDT600	Set-top box	Thomson 01788 541970
Thomson	DTI1550	Set-top box	Thomson 01788 541970
Thomson	DTI1500	Set-top box	Thomson 01788 541970
Grundig	GDT1000	Set-top box	Grundig 0871 230 1777
Grundig	GDT1500T	Set-top box	Grundig 0871 230 1777
Astratec	TOPD1	Top Up TV Set-top box	Step- 01 contact@step01.co.uk
Humax	MG-TU1	Top Up TV Set-top box	Humax 0870 247 8800
Matsui	TUTV1	Top Up TV Set-top box	Step- 01 contact@step01.co.uk
Ferguson	FDT2500	Top Up TV Set-top box	Step- 01 contact@step01.co.uk
<b>Where possible, manufacturers will produce solution in the form of an over air download (OAD) or DVD based update.</b>			
Echostar	T101	Set-top box	OAD 18-21 Sept 09 Almelo.service@echostar.com
Samsung	LExxR41 series	Integrated digital television (IDTV)	OAD Made 08442 449 999
Samsung	LExxR51 series	Integrated digital	OAD Made

		television (IDTV)	08442 449 999
Panasonic	DMR ES20D	DVD Recorder	DVD available 0870 535 7357
Panasonic	DMR EH60D	DVD Recorder	DVD available 0870 535 7357
Sagem	PVR6240 – 6280	HDD Recorder	OAD Made 0871 075 0710
Sagem	DTR6240 – 6280	HDD Recorder	OAD Made 0871 075 0710
Thomson	DTI6300	TUTV Recorder	OAD Made 01788 541970
<b>Products that have not received an OAD freeze when receiving the first multiplex.</b>			
Sony	KD-28DX40U	IDTV	Sony 0870 511 1999
Sony	KD-32DX100U	IDTV	Sony 0870 511 1999
Sony	KD-32DX40U	IDTV	Sony 0870 511 1999
Sony	KD-32NX100U	IDTV	Sony 0870 511 1999
Sony	KD-32DX150U	IDTV	Sony 0870 511 1999
Sony	KD-36NX200U	IDTV	Sony 0870 511 1999
Sony	KP-44DX2U	IDTV	Sony 0870 511 1999
Sony	KD-28DL10U	IDTV	Sony 0870 511 1999
Sony	KD-28DX200U	IDTV	Sony 0870 511 1999
Sony	KD-28DX50U	IDTV	Sony 0870 511 1999
Sony	KD-32DX150U	IDTV	Sony 0870 511 1999
Sony	KD-32DX200U	IDTV	Sony 0870 511 1999
Sony	KD-32DX50U	IDTV	Sony 0870 511 1999
Sony	KDE-P37XS1	IDTV	Sony 0870 511 1999
Sony	KD-EP24XS1	IDTV	Sony 0870 511 1999
Sony	KDL-L-32MRX1	IDTV	Sony 0870 511 1999
Sony	KDL-L42MRX1	IDTV	Sony 0870 511 1999
Sony	KDE-P42MRXI	IDTV	Sony 0870 511 1999
Sony	KDE-P50MRX1	IDTV	Sony 0870 511 1999
Sony	KDE-P61MRX1	IDTV	Sony 0870 511 1999